


NOTICE: When government or other drawings, specifications or other data are used for any purpose other than in connection with a definitely related government procurement operation, the U. S. Government thereby incurs no responsibility, nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use or sell any patented invention that may in any way be related thereto.

CATALOGED BY DDC  
AS AD No. 408503

408 503

63-4-2



Qualified requesters may  
obtain copies of this  
report from ASTIA.

# ALLEGANY BALLISTICS LABORATORY

Cumberland, Maryland

Operated by  
**HERCULES POWDER COMPANY**

for  
U.S. NAVY  
BUREAU OF NAVAL WEAPONS  
Contract NOrd 16640

DDC  
RECEIVED  
JUN 7 1963  
RECEIVED  
TISIA B

ABL/E-87

**A Temperature Measuring System  
Using RdF Stikon Resistance  
Elements**

**February 1, 1963**

**W. F. Dunn**

**Initial distribution of this report was made in accordance with the Joint-Army-Navy-Air Force Mailing Lists for Solid Propellants - dated June 1962.**

**Copy No. 176**

## TABLE OF CONTENTS

	<u>Page</u>
LIST OF FIGURES.....	v.
LIST OF TABLES .....	v
ABSTRACT.....	vii
I. INTRODUCTION .....	1
II. TEST PROCEDURES AND RESULTS.....	3
III. CONCLUSIONS AND RECOMMENDATIONS .....	9
IV. REFERENCE .....	9

### LIST OF FIGURES

	<u>Page</u>
Figure 1. RdF Stikon (BN-200T series).....	1
Figure 2. Resistance Change of an RdF Stikon (BN-200T series) ....	2
Figure 3. Bridge Circuit Used to Linearize the Output from an RdF Stikon .....	2
Figure 4. Linearity Curves for the Bridge Circuit (Using the Restance Values of a Freely Suspended Stikon).....	4
Figure 5. Apparatus Used in the Temperature Measuring System....	4
Figure 6. Comparison of the Accuracy of Unmounted Stikons to Stikons Bonded to Glass Fiber with Bakelite Cement.....	5
Figure 7. Strain Sensitivity of the C. P. Nickel Sensing Grid Used in an RdF Stikon.....	10

### LIST OF TABLES

Table I. Resistance Shift in the Bonded Stikon at 175.4° F .....	3
Table II. Methods Used to Mount Stikons to the Glass Fiber Surface.....	6
Table III. RdF Held to Glass Fiber with a Teflon Cover, Calibration Temperature at the Ice Point.....	7

## ABSTRACT

A temperature measuring system which uses RdF Stikon\* nickel resistance thermometer elements (BN-200T series) has been developed at Allegany Ballistics Laboratory (ABL). This system was developed as the result of a recognized need for a high-output temperature transducer compatible with present four arm bridge systems.

The RdF Stikon was tested in a bridge circuit designed to simulate a standard 350 ohm four arm bridge.

The Stikon was found to be sensitive to strain. Since it was to be used on surfaces of unpredictable strain, a strain-free method of surface attachment was developed.

The complete system was tested and found to have a system error of less than two percent when used in the 32° to 432° F temperature range.

---

\*Trademark of the RdF Corporation.

## INTRODUCTION

Transducers are used at ABL for measuring various data from test firings. Examples of these data are pressure, force and strain. Standardization of the various types of transducers would permit more efficient use of the present four arm bridge transducer conditioning system.

The RdF Stikon discussed here is a temperature transducer. A bridge circuit will be shown which will "standardize" the Stikon so that it will be compatible with four arm bridge transducer conditioning systems.

The Stikon is a resistance thermometer designed to measure surface temperature (see Figure 1). The Stikon uses a fine C. P. nickle wire grid as a temperature sensor. The resistance of the wire grid varies with its temperature. Resistance values for an unmounted Stikon were supplied by the manufacturer for a temperature range of  $-100^{\circ}\text{F}$  to  $+600^{\circ}\text{F}$  (see Figure 2.) Since the recorders used to read the Stikon temperature are linear devices, the shape of the C. P. nickle curve in Figure 2 had to be modified from the existing positively increasing slope. Modification was attained with a bridge circuit having a similar curve but with a positively decreasing slope; thus, when a Stikon was used with the bridge circuit, by the principle of superposition a linear output resulted. The bridge circuit used in the Stikon tests is shown in Figure 3.




FIGURE 1  
RdF Stikon (BN-200T Series)




FIGURE 2  
Resistance Change of an RdF Stikon (BN-200T Series)




FIGURE 3  
Bridge Circuit Used to Linearize the Output from an RdF Stikon



## TEST PROCEDURES AND RESULTS

The component values used in the bridge circuit were experimentally determined by substituting potentiometers for  $R_X$ ,  $R_A$ ,  $R_B$  and  $R_C$ . Values that gave best linearity as read on the 3 mv/v. scale of a transducer calibrator were used. A four step calibration was used having 100 Fahrenheit degrees per step. This allowed measurement of temperature changes up to 400 Fahrenheit degrees. The bridge circuit was checked for linearity at balance temperatures of 32°, 70°, 100° and 125°F. The results of this linearity check are shown in Figure 4.

The accuracy of the system was checked by using the Stikons with the bridge circuit and recording the results using a transducer calibrator designed for shunt calibrating four arm bridges. Ten unmounted Stikons were immersed in a Hallikainen Silicone Oil Bath Oven. The Stikons were balanced at 125°F on the transducer calibrator and the oven temperature was increased to 350°F with readings taken at every 20 or 30 degree temperature increment with Tagliabue (TAG) Extreme Precision Glass Thermometers (calibrated in tenths of a degree). Data readings were made after the silicone oil oven had maintained temperature equilibrium, to the nearest hundredth degree, for a period of ten minutes. The test equipment is shown in Figure 5 and the results are given in Figure 6.

The Stikons were then bonded to a glass fiber specimen approximately 3 inches square and similar tests were run in the silicone oil oven. The ice point was used in these tests so that a more useful temperature range could be covered. The results of these tests (see Figure 6 and Table I) indicated that the resistance characteristics of the Stikons were affected by strain resulting from thermal expansion of the glass fiber specimen. This gave poor results with the bridge circuit which was designed to operate with Stikons having the resistance characteristics shown in Figure 2.

Several strain-free methods of attachment were tested in a effort to reduce the strain error. The results of 2 of the more pertinent tests are given in Table II. Mount #3 (Teflon\*-covered Stikon) appeared to be the most satisfactory (see Table III).

TABLE I  
Resistance Shift in the Bonded Stikon at 175.4 °F

Unbonded Stikon	Bonded Stikon #1	Bonded Stikon #2	Bonded Stikon #3
269.7 $\Omega$	273.6 $\Omega$	271.4 $\Omega$	273.6 $\Omega$

---

\*duPont trademark.




FIGURE 4  
Linearity Curves for the Bridge Circuit (Using the Resistance  
Valves of a Freely Suspended Stikon)




FIGURE 5  
Apparatus Used in the Temperature Measuring System







FIGURE 6  
Comparison of the Accuracy of Unmounted Stikons to Stikons Bonded to Glass Fiber with Bakelite Cement

TABLE II  
Methods Used to Mount Stikons to the Glass Fiber Surface

MOUNT	COMMENTS
<p>#1</p>  <p>BAKELITE CEMENT UNDER ENTIRE STIKON</p>	<p>Good heat transfer, error resulting from thermal and physical strain (see Figure 6)</p>
<p>#2</p> <p>SILICONE RUBBER OVER CORNERS</p>  <p>OIL FILM UNDER STIKON</p>	<p>Gave good temperature readings, but heat made gage curl away from surface giving poor heat transfer.</p>
<p>#3</p> <p>OIL BUBBLE</p> <p>ADHESIVE</p>  <p>ETCHED TEFLON</p> <p>TEFLON COVER WITH STIKON. FREE FLOATING IN AN OIL BUBBLE</p>	<p>Good temperature readings (See Table III), oil insured a good thermal contact between Stikon and glass fiber. Not sensitive to strains and may be modified by adding a window over the sensitive wire grid. Teflon may be held in place with any contact cement or epoxy resin.</p>

**TABLE III**  
**RdF Held to Glass Fiber with a Teflon Cover, Calibration Temperature**  
**at the Ice Point**

Oil Bath Temperature	Temperature Indicated by RdF	Error	% Error
32.0°F	32.0°F	Calibration	—
64.0	65.0	+ 1	+ 1.5%
72.7	73.6	0.9	1.2
104.4	104.8	0.4	0.4
124.1	124.4	0.3	0.2
145.0	146.2	1.2	0.8
169.4	171.4	2.0	1.2
200.8	201.1	0.3	0.1
224.8	228.6	3.8	1.6
248.7	Pliobond Melted		

## CONCLUSIONS AND RECOMMENDATIONS

The bridge circuit (see Figure 3) was designed to be used with Stikons having the resistance characteristics shown in Figure 2. Bonding the Stikon to a glass fiber surface altered its resistance characteristics giving poor results with the bridge circuit (see Figure 6 and Table I). The resistance characteristics of the bonded Stikons were affected by the bakelite cement curing temperature, Stikon orientation and thermal warping of the glass fiber specimen. These factors indicate a sensitivity to strains of a magnitude (0 to 1.5%) normally encountered in ABL rocket motor testing (see Figure 7).

Several strain-free Stikon mountings were tried with mount #3 in Table II being recommended. The Stikon was surrounded with a thin film of oil which provided good surface lubrication as well as good heat transfer. The Stikon was insensitive to surface strains when mounted in this fashion. This type of mounting allowed the bridge circuit to be used effectively with the Stikon and resulted in a system error less than two percent (see Table III) when the bridge circuit was balanced at the ice point. If the balance point is 125°F, results similar to those of Figure 6 (unbonded Stikon) will be obtained. The two percent error was attributed to residual non-linearity in the bridge system (see Figure 4) and nominal resistance variation between Stikons.

Stikons used as described above are capable of measuring temperatures from 32°F to 432°F with an overall system error less than two percent even when large strains are present.

## REFERENCE

1. F. R. Maslen, "Note on the Strain Sensitivity of Platinum and Nickel in the Range 50° to 650° C, "Strain Gage Readings, Vol. 3, No. 6 (1961), Review 824, pp. 26-27.




FIGURE 7  
Strain Sensitivity of the C.P. Nickel Sensing Grid Used in an RdF Stikon<sup>(1)</sup>

UNCLASSIFIED

UNCLASSIFIED